

Welcome

09 50

08/02/16

TUE

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

MENU

Enroll

Setup

System Info

1

2

3

ESC

4

5

6

MENU

7

8

9



0

0

OK



LS-838

LoneStar

MENU



Enroll

Setup

System Info

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK




LS-838



LoneStar

Enroll 
User
Manager
Level Setting



LS-838



LoneStar

Enroll



User

Manager

Level Setting

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838



LoneStar

Manager ▼

Super Admin

Gen Manager

1

2

3

ESC

4

5

6

MENU

7

8

9




0


OK



LS-838

LoneStar

Enroll 
Manager
Level Setting
Delete




LS-838



LoneStar

Enroll ▲
Glog View
Slog View
AllLog Delete



LS-838



LoneStar

User

Finger

Card

Password

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

User ▲

Finger

Card

Password

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838



LoneStar

Finger

New Enroll?

No-ESC

Yes-OK

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

Backup

ID

00001

Esc-ESC

Set-OK

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

New Enroll

ID

00001

Esc-ESC

Set-OK

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

New Enroll

Press Finger #1

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

New Enroll

Press Finger #2

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

New Enroll

Press Finger #3

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK




LS-838

LoneStar

New Enroll

00001-0

Ign-ESC Sav-OK



LS-838



LoneStar

Finger

Continue?

No-ESC

Yes-OK

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

Delete

ID

00001

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

Delete

ID 00001-0

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

Delete

Delete?

No-ESC

Yes-OK

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

Delete

Continue?

No-ESC Yes-OK

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

All Log Delete

Delete?

No-ESC Yes-OK

1

2

3

ESC

4

5

6

MENU

7

8

9



0

0


OK



LS-838

LoneStar

Setup
System
Log Setup
Communication



LS-838



LoneStar

Communication ▼

Device ID 1

Baudrate 38400

Port No 5005

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838



LoneStar

Communication 

Port No 5005

Password No

IP Address

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

Communication 

Port No 5005

Password No

192.168.100.111

1

2

3

ESC

4

5

6

MENU

7

8

9






0


OK



LS-838

LoneStar

Communication 
IP Address
Subnet Mask
Default Gateway



LS-838



LoneStar

Communication 

Subnet Mask

192.168.100.254

RS485 Yes

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

Backup

Press Finger #1

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

Backup

Press Finger #2

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar

Backup

Press Finger #3

1

2

3

ESC

4

5

6

MENU

7

8

9



0

0

OK



LS-838

LoneStar

Backup

00001-0

Ign-ESC Sav-OK

1

2

3

ESC

4

5

6

MENU

7

8

9



0

OK



LS-838

LoneStar